

PANTHER™


By MarineTech

651-486-2010

info@marinetech.us

55-2750 DRIVE BRACKET ADAPTS TO SEASTAR

ITEM	DESCRIPTION	PART #	QTY
1	DRIVE BRACKET	99-02701	1
2	SPACER	99-02706	1
3	SHOULDER BOLT	99-55419	1
4	5/16" FLAT WASHER	99-55417	1
5	HHCS 5/16"-18 UNC 2-1/4" LONG	99-55426	1
6	FLANGED BUSHING	99-55168	1
7	5/16"-18 UNC NUT W/NYLON INSERT, THIN	99-55424	1
8	5/16"-18 UNC NUT W/NYLON INSERT	89-6704	1
9	FHCS 5/16"-18 UNC 7/8" LONG	99-55425	1



NOTES

1. This drive bracket may be used to connect the main engine steering bracket pivot plate to a tie bar or similar device to steer an auxiliary motor.
2. Prior to threading bolt [item 5] into main engine steering bracket the screw and stem washer must be removed from hydraulic steering unit bracket.

WARNINGS

1. Failure to follow these warnings and installations instructions could result in damage to main motor, trolling motor, tie bar, as well as cause property damage and/or result in death or serious injury.
2. Read, understand, and follow all instruction and warnings before using drive bracket kit. Additional copies can be obtained by contacting us at info@marinetech.us
3. Do not install or use this drive bracket kit in a manner inconsistent with USCG, BIA, or NMMA regulations or standards, or manufacturer's recommendations.
4. Do not modify this drive bracket kit in any way.
5. This drive bracket kit is to be used to steer auxiliary engines 40 HP or less.
6. Inspect drive bracket as well as main and trolling motor steering brackets for loose or damaged hardware prior to use. Tighten or replace hardware as needed.

REV 11/18